

Need a Leg Up on Support for Your Tools?

Van Mark now has the most rugged durable brake legs you can buy on the market today! UniLeg™ sets up fast and easy and with our unique leg flare-out design, you can rest assured your Van Mark tool is on stable footing.



Unique Flare-Out Design



Model No. 3005



TrimMaster® TM1060



Trim-A-Gutter™



Trim-A-Brake™



Mark I Series™ M1061

- **All-Steel Welded Construction**
- **Durable Powder-Coat Finish**
- **Fits Van Mark Brakes & Saw Tables**
- **UniLeg™ Does Not Rack-Rattle-Roll**
- **No Tools Needed-Single User Setup**