

## On UniLegs On the Brake

Image	Name	Description	Quantity	Part No
	Trim-A-Gutter™ Portable Gutter-Cover Tool	Forms industry standard 4 ft. lengths from standard trim coil or gutter coil. Tool comes complete with UniMount™ hardware for mounting to any Van Mark brake, or independently using UniLegs	1 Each	TAG50
	*5" Bracket	Fits 5 inch "K" style gutters. Aluminum extruded 2 step brackets first hang the gutter, then mount the gutter-cover. Can also be used to re-hang sagging gutters, or to hang custom 5" box gutter.	100 Count 500 Count	3026 3027
	*3" Anchors	Used to fasten bracket into the fascia.	100 Count 500 Count	3028 3029
	*3/8" Stainless Cover Screws	Attaches gutter-cover to bracket. Other uses include fastening outer edge of gutter into bracket, installing splash guards and end caps.	100 Count	3030
			500 Count	3031
0	1/4" Magnetic Bit Driver	1/4" Magnetic Bit Driver-When used with a cordless drill, used to drive anchors & cover screws in place.	1 Each	4629
	UniLeg™ Tool Supports	For mounting TAG50 independent from Van Mark brake. Unilegs™ also fits other popular Van Mark tools.	1 Pair	3005

\*This item not available in single quantity.