



INSTALLATION INSTRUCTIONS

1. Install end cap(s) as needed
 - Slide end cap into the screen track (over screen) push till tight against panel. Place panel tight against end cap to start your run.
2. Fastening Max Flo
 - Make sure front of panel is over nose of gutter
 - Screw #8 x 1/2" screw at each end and one in the middle (screws included)
 - For 8' panels, place screws approx. every 24" apart
3. Max Flo is designed to fit snugly under the drip edge against the back of the fascia.
 - Screw #10 x 1" screws to the back of the panel into the fascia
 - **IMPORTANT: DO NOT** screw #10 x 1" screw to the front of the panel as it will most likely result in some distortion of the panel and gutter.
4. Measure the end of run and cut panel using snips or a metal saw, ensure end caps are firmly inserted.



1.



2.



3.



4.